

Bleed air from the hydraulic system:

- 1) Use the installed spreader or install a loop into the pressure & return line for both auger/conveyor & spinner circuit.
- 2) Engage spreader circuit (electrical or manual over-ride) at "mid range" running speed;
- 3) Actuate each implement and "dead head" (hold in maximum position) for 30 seconds in each direction (up and then down); (electric or manual overrides ok to dead head the implement);
 - a) Start with implement whose valve is closest to the valve inlet – normally the hoist;
 - b) Repeat steps in order for each implement on truck;
 - c) Entrapped air has been minimized if implement moves smoothly when actuated;
 - d) For single acting implements, consult the implement manufacturer for proper bleeding of air.
- Remove installed plumbing loop (if you used one).
- Air bleeding is complete.

Common Startup issues in Hydraulic Systems

- Entrap air in system
 - Bleed air from system;
 - Seal fittings properly;
- Debris in fluid
 - Clean all hoses after installing fittings to remove hose debris before installing hoses;
 - Run system for 30 minutes. Check filter element for debris and replace if debris is present;

For more detailed information

- Consult manual and drawings contained on the CD with this shipment

9210 Wyoming Ave N. Suite 200 Brooklyn Park, MN 55445
Ph:763-493-9380 F:763-493-9340 www.ciruscontrols.com



**Installation of Mobile Hydraulic Valve Assembly
for Snow & Ice Applications**

Rev C 1/08

Hydraulic hose pressure rating must exceed the inlet pressure relief setting of the valve:

3,000 psi minimum




Hose Cleanliness – critical performance factor

- Blow out hose debris after terminating hose with fittings and before installing hose onto system;

Hose Routing


- 1) Hoses must be routed to achieve maximum saturation with fluid at the pump with the fewest number of **90 degree fittings**.




- 2) Improper routing of hoses can increase the noise of the system in operation. Avoid contact between truck frame and any fittings; Isolate and wrap any places where fitting to frame contact must occur.

Hose and fittings sizing must match the port size of the pump and the valve:

Do not use reducing fittings;



Avoid elbow fittings



Plumbing to the valve:


Port A is always for “return line” (cylinder rod)

e.g.: hoist down, plow down, wing toe down, etc.

Port B is always for “power line” (cylinder base)

e.g.: hoist up, plow up, wing toe up, etc

Consult master drawing for A/B port location on your valve.



Warning		Potential for injury due to unexpected operation of system. Entanglement with implements will cause severe injury to extremities; Stay clear of all implements during all startup, programming and operation procedures. Implements may move without warning.
----------------	--	---

Pressure Settings are Critical for Proper Operation

- Complete all hydraulic plumbing to allow operation of all functions and complete the pump commissioning procedure before beginning valve commissioning;

- Install gauge at valve inlet (if not installed):

- Start up vehicle, engage prime mover (or PTO), allow truck to idle;

- **Observe pressure on valve inlet -Standby Pressure– 250-400 psi;** if not in this range, see pump pressure setting procedure to adjust;

- To check system pressure, briefly “dead head” and observe gauge. Release immediately if pressure exceeds 2500psi.

- **Main System pressure – 2500 psi (factory setting).**

Consult manufacturer's recommendations for special applications or other pressure settings;



- **Individual section relief valves**

Consult your manual to determine if your valve has settable section reliefs.