



**TECH NOTE:** 11-009  
**TITLE:** Conversion Matrix for Spreader Blocks  
**DATE:** 07-12-11  
**REVISION:** 1.0

Open Center blocks				
	Remove		Add	
<b>Cirus P/N</b>	<b>HYDJ01</b>	<b>to</b>	<b>HYDJ03</b>	
<b>Functions</b>	Aug, Spin, PreWet		Aug, Spin	
<b>P/N's</b>	4303212	1 pc.		
			515-10	1pc.
PV72-30AG-0-N-00	1 pc.		515-12	1 pc.
CV04-20-0-N-4	1 pc.		CP04-20-N	1 pc.
OR10035-35	1 pc.		OR10035-040	1 pc.

Closed Center Blocks				
	Add			Remove
<b>Cirus P/N</b>	<b>HYDJ02</b>	<b>to</b>	<b>HYDJ04</b>	
<b>Functions</b>	Aug, Spin, PreWet		Aug, Spin	
<b>P/N's</b>	515-12	1 PC.	PV72-30AG-0-N-00	1 PC.
	515-10	1 PC.		
PV72-30AG-0-N-00			4303212	1 PC.
CP04-20-N	1 PC.		CV04-20-0-N-4	1 PC.

	Remove		Add	
<b>Cirus P/N</b>	<b>HYDJ03</b>	<b>to</b>	<b>HYDJ01</b>	
<b>Functions</b>	Aug, Spin		Aug, Spin, PreWet	
<b>P/N's</b>				
			4303212	1 PC.
515-12	1 pc.		PV72-30AG-0-N-00	1 pc.
CP04-20-N	1 pc.		CV04-20-0-N-4	1 pc.
OR10035-040	1 pc.		OR10035-35	1 pc.
515-10	1 pc.			

	Add			Remove	
<b>Cirus P/N</b>	<b>HYDJ04</b>	<b>to</b>	<b>HYDJ02</b>		
<b>Functions</b>	Aug, Spin		Aug, Spin, PreWet		
<b>P/N's</b>					
	4303212	1 PC.			
PV72-30AG-0-N-00	1 PC.		515-12	1 PC.	
			515-10	1 PC.	
CV04-20-0-N-4	1 PC.		CP04-20-N	1 PC.	

**Sample Conversion adding Pre-Wet components (from HYDJ103 to HYDJ101 or HYDJ104 to HYDJ102)**

**B.O.M.**

<u>Item #</u>	<u>Quan</u>	<u>Part Number</u>	<u>Description</u>
A	1	PV72-30AG-0-N-00	Proportional flow control
B	1	4303112	Solenoid coil (Metripack)
C	1	CV04-20-0-N-4	Check valve

Remove the plug (item 1 on Figure 1) and the cavity plug (item 2 on Figure 1).




Figure 1




Figure 2

Install item "C" where item 2 was (torque to 20 ft lbs.) (See Figure 2).

Next install Item "A" where item 1 was (torque to 35 ft lbs.) (See Figure 2).

Then install item "B" onto item "A", tighten nut snug. (See Figure 2)