

HYDRAULICS

CONTROLS

REPORTING

Reliable integrated controls for plowing and spreading

The Barracuda™ electronic control system is designed to control dump, plow, tarp, granular and pre-wet applications. It combines full functionality and user-friendly operations in a compact package.

DUMP/PLOW CONTROLS

Proportional, incremental control for:

- Dump hoist (up/down)
- Plow lift (up/down)
- Plow reverse (left/right)

SPREADER CONTROLS

- Includes 3 channels for 2- or 3-channel operation
- Open-loop control for auger, spinner and auxiliary (pre-wet, X-conveyor) channels
- · Adjustable settings from min to max
- Ground-speed oriented or manual spreader control
- Backlit control panel
- Keypad controlled trim settings (no trim pots)

TARP CONTROL

• Operator control for bi-directional tarp (electronic or hydraulic) - electrical relays not included

WARNING LIGHTS

• Body Up, Low Oil, Filter Clog

AUTO SHUTDOWN CIRCUITS

• Low Oil shut down and override circuit (requires sensor) and Body Up limit circuit (requires sensor)

PROPORTIONAL CHANNELS

• Independent control of 9 proportional channels

HYDRAULIC TRIMMING

• Configuration mode for hydraulic trimming without manual trim pots



9-channel control

GROUND SPEED OPTIONS

- Ground speed triggered (GST): starts with truck motion, off when truck stops
- Ground speed oriented (GSO): on with truck motion, automatically adjusts output to compensate for truck speed, off when truck stops
- Manual: no ground speed interaction

BLAST AND PAUSE

- Programmable blast included (on/off, timed)
- Use pause switch to pause spreading (with power on)
- System powers up in "pause" to prevent unintentional spreading

OUTPUT SIGNAL

· Multiple frequency settings for ease of valve compatibility

POWER SAFETY

- Power Safe[™] signal prevents random grounds powering any attached hydraulics system
- Channel Safe™ detects and protects against open or short circuits on hydraulic drive channels

OPERATING TEMPERATURE RANGE

• Minimum: -20 degrees Celsius, Maximum: 70 degrees Celsius

POWER REQUIREMENTS

• Minimum: 11 Volts DC

• Maximum: 10 Amps

• Maximum: 15 Volts DC

• Fuse rated at 10 Amps



certifiedpowersolutions.com

Certified Power Solutions

Minneapolis, MN 763-493-9380 cps-mn@certifiedpower.com

Chicago, IL 847-573-3800 cps-il@certifiedpower.com

Des Moines, IA 515-244-7411 cps-ia@certifiedpower.com

St. Louis, MO 314-344-3300 cps-mo@certifiedpower.com

Toledo, OH 419-873-7411 cps-oh@certifiedpower.com